

# INSTALLATION

## INSTRUCTIONS

### Booster Installer



*Place staub in base*



*Place booster over staub*



*Place insert into booster*



*Put 3/8 bolt through center of booster insert*



*Tighten bolt until booster is fully installed*

**Bo Laws Performance  
Products, Inc.**

1015 West Church Street  
Orlando, Florida 32805  
407.422.0394  
800.624.1358  
407.422.2741 fax

**WWW.BLP.COM**